

October 13, 2011

Acer® ICONIA™ Tablets & Touchbook - Optional Accessories					
Accessory	SKU	Tablets			Touchbook
		A100	A500	W500	6120
Capacitive Stylus: Rubber-tip stylus plus ballpoint pen in one. Case included.	LC.ACC0A.026	X	X	X	
External Optical Drive: USB 2.0 8X DVD-RW (black)	LC.ODD00.013	X	X	X	X
AC Power Supply Travel Pack: AC adapter with snap-in US, UK and EU power plugs	LC.ADT0A.024	X	X		
Bluetooth® 2.0 Keyboard: Powered by AAA battery (included), lightweight design, fits into carry-on luggage	LC.KBD0A.014	X	X		
A5 Anti-Glare Protective Film	LC.ACC0A.020		X		
10" Black Case: Back cover folds to prop up tablet, easy access to all buttons and ports, durable and protective	LC.BAG0A.045		X		
Docking Station with IR Remote: Built-in charging connection, headphone and power connectors, Micro HDMI® port, 20° angle for typing, 70° angle for viewing	LC.DCK0A.006		X		
7" Black Case: Back cover folds to prop up tablet, easy access to all buttons and ports, durable and protective	LC.BAG0A.060	X			
W5 Anti-Glare Protective Film	LC.ACC0A.024			X	
40W AC Adapter	LC.ADT0A.023			X	
Protective Carrying Case	LZ.23800.013			X	
Keyboard Dock: Identical to the one that comes with the W500	LC.KBD00.060			X	